


Quartet Keypad Quick Reference



How the Keypad Works

Press Means to press the key once.

Press and Hold Means to press the key and hold it down.

Shift Means to press STOP and MODE at the same time, followed by another key indicating the function.

Table 1: Source and Room Names

Key	Source Name	Room Name
S1		
S2		
S3		
S4		



Quartet Keypad Quick Reference

Table 2. Function Quick Reference

Function	Description	Press Button
Select a source.	Selects a source for that room.	Press S1, S2, S3, S4 or FM, depending on desired source.
Select a source for all rooms.	Selects a source for all rooms (Party mode).	Press and hold S1, S2, S3, S4 or FM.
Select a local source.	Selects a local source.	Press AUX. Select a room (the available rooms will be blinking).
Select FM tuner.	Selects the FM tuner.	Press the FM button.
Manually tune radio.	Manually tunes the FM radio.	Press the left or right arrow buttons.
Seek up or down.	Automatically goes to the next or previous radio station.	Press and hold the left or right arrow buttons.
Turn DND ON or OFF.	Turns room DND mode ON or OFF.	Press STOP and MODE key, then press 4. The DND light will turn ON/OFF.
Turn room privacy ON or OFF.	Turns room privacy mode ON or OFF.	Press STOP and MODE key, then press 5. The MON light will turn ON/OFF.
Turn room monitoring ON.	Triggers room monitoring mode.	Press STOP and MODE key, then press 6. Select a room (the available rooms will be blinking).
Turn room monitoring OFF.	Turns room monitoring OFF.	Select the room to monitor by pressing S1-S4.
Turn sleep ON or OFF.	Turns sleep mode ON or OFF.	Press STOP and MODE key, then press 7.
Select preset 0-9.	Selects FM tuner preset 0-9.	Press 0 - 9 key.
Select preset 10-19.	Selects FM tuner preset 10-19.	Press and hold 0-9 key.
Mute or unmute room.	Mutes or unmutes room.	Press TALK/MUTE once to mute; press again to unmute.
Turn all rooms OFF.	Turns all rooms OFF.	Press and hold MODE key for two seconds with the STOP key to enter key shift mode. After entering key shift mode, press the MODE key again to turn all rooms OFF.
Set room to INT amplifier.	Sets room to INT amplifier.	Press STOP and MODE key, then press 1.
Set room to AUX output for local amplifier.	Sets room to AUX output for local amplifier.	Press STOP and MODE, then press 2.
Set room to INT+AUX output.	Sets room to INT+AUX output.	Press STOP and MODE, then press 3.
Room to room paging.	Room to room paging.	Press TALK/MUTE for one second, then press S1, S2, S3, or S4.
Set room to RNR.	Sets room to Rest and Rise.	Press STOP and MODE, then key 8 to turn RNR ON. Press STOP and MODE, then key 8 again to turn RNR OFF.