

MUSICA™ Technical Bulletin

Programming Station Presets for *Musica* FM Keypad

The *Musica* MU4602KP50-FM and MU5066KP50-FM allows you to program eight FM stations for preset playback. To create a preset, complete the following steps:

1. Tune to the station you want to program in (for example, 101.3).
2. Press and hold the **Mode** key.
The "P" on the LCD begins flashing (see Figure 1).




Figure 1 Location of "P" (preset)

3. Press and hold hard key 1 for five seconds.
The LCD menu confirms storage of that station as a preset.

The
IP-Based
Distributed
Entertainment
Company.

Products Included:

Musica 4602

Musica 5066

MU4602KP50-FM

MU5066KP50-FM

