

Sending Configuration

Any time you edit device information, the data isn't applied to the physical device until you send the configuration.

Sending Configuration Using the Dealer Setup Wizard

To send configuration files to the live devices, complete the following steps:

NOTE: If you want to edit details of the live devices prior to sending the configuration out to them, select **Cancel** and refer to *Editing Devices* in Chapter 5. You can return to push the configuration to the live devices by selecting the **Send Config Files** button on the bottom of your screen.

1. Highlight individual devices to send configuration to or use the **Select All** button to select all devices to be configured.
2. Select **OK** to send the configuration.

The configuration is downloaded, and the selected live devices are restarted. You are prompted that the configuration is complete (see Figure 6-1).




Figure 6-1 Configuration Complete prompt

Finishing the Project

1. Select **Finish** from the Dealer Setup Wizard.
The setup is complete.
2. Select **File>Save** to save the project.
3. Close the Dealer Setup program.



Sending the Configuration Without the Wizard

If you are not in the Dealer Setup Wizard, complete the following steps:

1. With the project open to the changes you just made, select one of the Send Configuration icons (see Table 6-1).

Table 6-1

Send Configuration Icons

	Send Configuration to Device
	Send Configuration to Multiple Devices

2. Select **File>Save** to save the project.